


## To change the batteries on the Doorbell (Non-Video):

- Insert a small flat head screwdriver at the top of the backplate to remove it.
- Use the battery pull tab to remove the old battery.
- Reinsert the pull tab and new CR2032 3V battery. The plus (+) side of the battery should be facing up.
- Secure the doorbell to the backplate ensuring the drain (weep hole) is facing downward.



If you require assistance with any step of your battery installation please contact us at **1-866-476-0420**.