



To change the batteries on the Panic Button Remote:

- Insert a small, flathead screwdriver (B) into the opening on the panic button (A). Then remove the top cover.



- Gently insert the flathead screwdriver between the battery (A) and one of the metal clips (B) in the battery compartment. Then remove the old battery.



- Insert the replacement CR2032 3V battery with the positive (+) sign facing up.
- Replace the panic button's top cover.

If you require assistance with any step of your battery installation please contact us at **1-866-476-0420**.