Charging The Battery

eastlink

The wireless doorbell will display alternating red and blue lights on the button's LED to indicate a low battery. The battery is estimated to last up to 6 months on a single charge, depending on usage.

Charging Requirements

- A 5V/1.5A USB wall charger
- The supplied charging cable

Charging Steps

Note: A fully depleted battery takes approximately 7 hours to charge.

1. Unlatch the bottom of the mount.

2. Remove the VDB780B from the mount.

3. Separate the battery pack from the VDB780B body.

4. Plug the supplied micro USB cable into the battery pack.

5. Plug the USB end of the cable into a USB wall charger and insert the charger into an outlet.

6. The charging LED, located on the top of the battery pack, will be solid orange while the device is charging. The charging LED will turn solid green when charging has completed.